

# ViPrimePLUS *Taq* qPCR Green Master Mix II (EvaGreen® Dye)

Product code:
Packsize:

150 reactions

QLMM17

Lot No.: Expiry Date:

# **DESCRIPTION**

ViPrimePLUS Tag qPCR Green Master Mix II is next generation master mix designed for fast and easy realtime PCR reaction set up. The master mix is prepared in 2X concentrated solution and contains pure Tag DNA Polymerases, EvaGreen® dye, highest quality and buffer components at optimal concentrations. Taq DNA Polymerases in the master mix provide excellent results in reaction efficiency, correlation coefficient and slope. EvaGreen® dye in master mix is environmentally safe and highly stable which can be formulated with relative high dye concentration to maximize fluorescence signal without PCR inhibition.

ViPrimePLUS *Taq* qPCR Green Master Mix II can be used to amplify any DNA template including genomic, cDNA and viral sequences. The formulation of qPCR green master mix can detect low copy number targets very specifically with high efficiency. The qPCR green master mix provides convenient and robust set up for quantitative real-time analysis of DNA samples.

ViPrimePLUS *Taq* qPCR Green Master Mix II has several formulations optimized to be used with most of real-time PCR instruments. The improved sensitivity and consistency of ViPrimePLUS *Taq* qPCR Green Master Mix II in standard cycling conditions gives the industry leading performance in fast cycling conditions.

#### **APPLICATIONS**

All kinds of sample material suited for qPCR amplification can be used.

#### **FEATURES**

- Ready-to-use real-time PCR reaction set up
- Rapid extension rate for early Ct values
- Good buffer system for excellent amplification efficiency
- Contain EvaGreen® dye highest dye stability and safety
- High sensitivity detection
- Minimal PCR inhibition
- Compatible with most of the real-time PCR platforms

## **COMPONENTS**

1.6ml aliquots of master mix

#### STORAGE

Stable at -20°C up to the expiry date stated. Store all components at -20°C upon arrival. Keep in aliquot to reduce freeze-thaw cycles.

#### **QUALITY CONTROL**

As part of the ISO9001:2008 quality assurance systems, each lot of ViPrimePLUS *Taq* qPCR Green Master Mix II has been tested against predetermined specifications to ensure consistent product quality and highest levels of performance and reliability.

#### **LIMITATION OF USE**

For research use only. Not recommended or intended for diagnosis of disease in humans or animals. Do not use internally or externally in humans or animals.

#### **INSTRUMENTS**

To calibrate a real-time PCR reaction, various formulations of master mixes are available for most of the platforms.

# **Master Mixes with Compatible Hardware**

QLMM17

ViPrimePLUS *Taq* qPCR Green Master Mix II (EvaGreen® Dye)

Biometra qTower, BioRad iCycler, BioRad IQ4, BioRad IQ5, Cepheid SmartCycler®, Eppendorf Mastercycler, Fluidigm BioMark™, Illumina Eco, MJ Chromo4, Opticon, PCRMax Eco™, Roche lightcycler® 480, lightcycler® LC96 and lightcycler® Nano Platforms, RotorGene, Roche Capillary Lightcycler 1.0-2.0, Stratagene MX MX4000P®, MX3000P®, MX3005®, Thermo PikoReal™

QLMM17-LR

ViPrimePLUS *Taq* qPCR Green Master Mix II with Low ROX (EvaGreen® Dye)

Applied Biosystems 7500 and 7500 FAST platform, QuantStudio™, ViiA7

QLMM17-R

ViPrimePLUS *Taq* qPCR Green Master Mix II with ROX (EvaGreen® Dye)

Applied Biosystems 7000, 7300, 7700, 7900 and 7900HT FAST platforms, GeneAmp® 5700, StepOne™, StepOne™ PLUS

#### **PROTOCOL**

- 1. Keep the qPCR green master mix protected from light before and after use.
- 2. Aliquot the qPCR green master mix to minimize freeze-thaw cycles and light exposure.
- 3. Reserve plate positions for positive (control DNA) and negative (water or buffer) controls.
- 4. When preparing mixes, always calculate the volume according to the number of reactions that needed plus one extra.
- 5. After the mixture is prepared and aliquoted into tubes, place them into qPCR platform.

#### SUGGESTED MIXTURE

a. When using ViPrimePLUS gene detection kits:

Components	Reaction (1X)
	Neaction (1X)
Taq qPCR Green Master Mix II	10µl
Primer/Probe Mix	1µl
Template (25ng)	5µl
Nuclease free water	4µl
Final Volume	20µl

b. When using user's supplied primers and probe:

Components	Reaction (1X)
Taq qPCR Green Master Mix II	10µl
Primers (6pmols Forward & Reverse)	Χμl
Probe (3pmols)	Χμl
Template (25ng)	Χμl
Nuclease free water	Χμl
Final Volume	20µl

#### **CYCLING PROGRAM**

a. For Tagman® gene detection kits

Step	Cycles	Temp	Time
Enzyme activation	1	95°C	2mins
Denaturation	40**	95°C	15secs
Data Collection*		60°C	60secs

<sup>\*</sup>Fluorogenic data should be collected during this step through the FAM channel.

# b. For EvaGreen® detection kits

Step	Cycles	Temp	Time
Enzyme activation	1	95°C	2mins
Denaturation	40***	95°C	15secs
Data Collection*		60°C	60secs
Melt Curve**			

<sup>\*</sup>Fluorogenic data should be collected during this step through the EvaGreen® channel.

# PREVENTION OF CONTAMINATION

qPCR amplification is a very sensitive DNA amplification reaction; therefore extra care should be taken to eliminate the possibility of contamination with any foreign DNA templates.

- Use separate clean areas for preparation of samples, reaction mixture and for cycling.
- Clean lab bench and equipments periodically with 3% hydrogen peroxide or 70% ethanol.
- Wear fresh gloves. Change gloves whenever suspect that they are contaminated.
- Use sterile tubes and pipette tips with aerosol filters for PCR reaction set up.
- With every PCR reaction set up, perform a contamination control reaction without template DNA.

#### TROUBLESHOOTING

IK	COUBLESHOOTING	
	Possibility	Suggestion
	roblem: Negative cor ives positive result	ntrol / no template control
1	. Carry over contamination	Change nuclease-free water. Use fresh aliquots of reagents. Use filtered tips. Load positive control last.
Р	roblem: No signal de	tected
1	<ul> <li>Incorrect programming of instrument</li> </ul>	Check program.
2	. Reagents expired	Check the expiry date of reagents before repeat.
3	. Storage condition not complying with instructions	Check storage condition properly and store at correct storage condition to avoid the degradation of reagents.
Р	roblem: Early / late s	ignal detected than expected
	Genomic     DNA/RNA     contamination or     multiple products	DNase or RNase treatment of template before qPCR; re- design primers to increase specificity
2	<ul> <li>Unspecific products or primer dimers detected</li> </ul>	Re-design primers to increase specificity
3	Limiting reagents     or degraded     reagents such as     master mix	Check calculations for master mix; repeat experiment using fresh stock solutions
4	. Poor efficiency	Re-design primers to a

# LEGAL DISCLAIMER

during PCR

5. Unanticipated

variants within

target seguence

reaction

Purchase of product does not include a license to perform any patented applications; therefore it is the sole responsibility of users to determine whether they may be required to engage a license agreement depending upon the particular application in which the product is used.

sequence

different region of the target

Keep the GC content to

between 30-50%

#### WARRANTY AND LIMITED LIABILITY

The performance characteristics stated were obtained using the assay procedures in the insert. Failure to comply with the instructions may derive inaccurate results. In such event, manufacturer disclaims all warranty expressed, implied or statutory including the implied warranty of merchantability and the fitness of use.

The manufacturer will not be liable for any damage caused by misuse, improper handling and storage; non-compliance with precautions and procedures, and damages caused by events occurring after the product is released.

EvaGreen® is a registered trademark of Biotium, Inc.

<sup>\*\*</sup>A further 10 cycles can be added to generate the complete amplification plot for low copy number targets which giving late detection.

<sup>\*\*</sup>A post PCR run melt curve can be used to prove the specificity of primers. See the manufactures instructions for your hardware platform.

<sup>\*\*\*</sup>A further 10 cycles can be added to generate the complete amplification plot for low copy number targets which giving late detection.



# ViPrimePLUS *Taq* qPCR Green Master Mix II with Low ROX (EvaGreen® Dye)

Product code: Packsize:

QLMM17-LR

Lot No.:

150 reactions

Expiry Date:

#### **DESCRIPTION**

ViPrimePLUS Tag qPCR Green Master Mix II is next generation master mix designed for fast and easy realtime PCR reaction set up. The master mix is prepared in 2X concentrated solution and contains pure Tag DNA Polymerases, EvaGreen® dye, highest quality and buffer components at optimal concentrations. Taq DNA Polymerases in the master mix provide excellent results in reaction efficiency, correlation coefficient and slope. EvaGreen® dye in master mix is environmentally safe and highly stable which can be formulated with relative high dye concentration to maximize fluorescence signal without PCR inhibition.

ViPrimePLUS *Taq* qPCR Green Master Mix II can be used to amplify any DNA template including genomic, cDNA and viral sequences. The formulation of qPCR green master mix can detect low copy number targets very specifically with high efficiency. The qPCR green master mix provides convenient and robust set up for quantitative real-time analysis of DNA samples.

ViPrimePLUS *Taq* qPCR Green Master Mix II has several formulations optimized to be used with most of real-time PCR instruments. The improved sensitivity and consistency of ViPrimePLUS *Taq* qPCR Green Master Mix II in standard cycling conditions gives the industry leading performance in fast cycling conditions.

#### **APPLICATIONS**

All kinds of sample material suited for qPCR amplification can be used.

#### **FEATURES**

- Ready-to-use real-time PCR reaction set up
- Rapid extension rate for early Ct values
- Good buffer system for excellent amplification efficiency
- Contain EvaGreen® dye highest dye stability and safety
- High sensitivity detection
- Minimal PCR inhibition
- Compatible with most of the real-time PCR platforms

## **COMPONENTS**

1.6ml aliquots of master mix

#### STORAGE

Stable at -20°C up to the expiry date stated. Store all components at -20°C upon arrival. Keep in aliquot to reduce freeze-thaw cycles.

#### **QUALITY CONTROL**

As part of the ISO9001:2008 quality assurance systems, each lot of ViPrimePLUS *Taq* qPCR Green Master Mix II has been tested against predetermined specifications to ensure consistent product quality and highest levels of performance and reliability.

#### **LIMITATION OF USE**

For research use only. Not recommended or intended for diagnosis of disease in humans or animals. Do not use internally or externally in humans or animals.

#### **INSTRUMENTS**

To calibrate a real-time PCR reaction, various formulations of master mixes are available for most of the platforms.

# **Master Mixes with Compatible Hardware**

QLMM17

ViPrimePLUS *Taq* qPCR Green Master Mix II (EvaGreen® Dye)

Biometra qTower, BioRad iCycler, BioRad IQ4, BioRad IQ5, Cepheid SmartCycler®, Eppendorf Mastercycler, Fluidigm BioMark™, Illumina Eco, MJ Chromo4, Opticon, PCRMax Eco™, Roche lightcycler® 480, lightcycler® LC96 and lightcycler® Nano Platforms, RotorGene, Roche Capillary Lightcycler 1.0-2.0, Stratagene MX MX4000P®, MX3000P®, MX3005®, Thermo PikoReal™

QLMM17-LR

ViPrimePLUS *Taq* qPCR Green Master Mix II with Low ROX (EvaGreen® Dye)

Applied Biosystems 7500 and 7500 FAST platform, QuantStudio™, ViiA7

QLMM17-R

ViPrimePLUS *Taq* qPCR Green Master Mix II with ROX (EvaGreen® Dye)

Applied Biosystems 7000, 7300, 7700, 7900 and 7900HT FAST platforms, GeneAmp® 5700, StepOne™, StepOne™ PLUS

#### **PROTOCOL**

- 1. Keep the qPCR green master mix protected from light before and after use.
- 2. Aliquot the qPCR green master mix to minimize freeze-thaw cycles and light exposure.
- 3. Reserve plate positions for positive (control DNA) and negative (water or buffer) controls.
- 4. When preparing mixes, always calculate the volume according to the number of reactions that needed plus one extra.
- 5. After the mixture is prepared and aliquoted into tubes, place them into qPCR platform.

#### SUGGESTED MIXTURE

a. When using ViPrimePLUS gene detection kits:

Components	Reaction (1X)
Taq qPCR Green Master Mix II	10µl
Primer/Probe Mix	1µl
Template (25ng)	5µl
Nuclease free water	4µl
Final Volume	20µl

b. When using user's supplied primers and probe:

Components	Reaction (1X)
Taq qPCR Green Master Mix II	10µl
Primers (6pmols Forward & Reverse)	Χμl
Probe (3pmols)	Χμl
Template (25ng)	Χμl
Nuclease free water	Χμl
Final Volume	20µl

#### **CYCLING PROGRAM**

a. For Tagman® gene detection kits

Step	Cycles	Temp	Time
Enzyme activation	1	95°C	2mins
Denaturation	40**	95°C	15secs
Data Collection*		60°C	60secs

<sup>\*</sup>Fluorogenic data should be collected during this step through the FAM channel.

#### b. For EvaGreen® detection kits

Step	Cycles	Temp	Time
Enzyme activation	1	95°C	2mins
Denaturation	40***	95°C	15secs
Data Collection*		60°C	60secs
Melt Curve**			

<sup>\*</sup>Fluorogenic data should be collected during this step through the EvaGreen® channel.

### PREVENTION OF CONTAMINATION

qPCR amplification is a very sensitive DNA amplification reaction; therefore extra care should be taken to eliminate the possibility of contamination with any foreign DNA templates.

- Use separate clean areas for preparation of samples, reaction mixture and for cycling.
- Clean lab bench and equipments periodically with 3% hydrogen peroxide or 70% ethanol.
- Wear fresh gloves. Change gloves whenever suspect that they are contaminated.
- Use sterile tubes and pipette tips with aerosol filters for PCR reaction set up.
- With every PCR reaction set up, perform a contamination control reaction without template DNA.

#### TROUBLESHOOTING

Possibility	Suggestion	
Problem: Negative control / no template control gives positive result		
Carry over contamination	Change nuclease-free water. Use fresh aliquots of reagents. Use filtered tips. Load positive control last.	
Problem: No signal de	tected	
Incorrect     programming of     instrument	Check program.	
2. Reagents expired	Check the expiry date of reagents before repeat.	
3. Storage condition not complying with instructions	Check storage condition properly and store at correct storage condition to avoid the	
IIIStructions	degradation of reagents.	
Problem: Early / late s	ignal detected than expected	
Genomic     DNA/RNA     contamination or	DNase or RNase treatment of template before qPCR; redesign primers to increase	
multiple products	specificity	
Unspecific products or primer dimers detected	Re-design primers to increase specificity	
3. Limiting reagents	Check calculations for master	

 Limiting reagents or degraded reagents such as master mix

4. Poor efficiency during PCR reaction

5. Unanticipated variants within target sequence

Check calculations for master mix; repeat experiment using fresh stock solutions

Re-design primers to a different region of the target sequence

Keep the GC content to between 30-50%

# LEGAL DISCLAIMER

Purchase of product does not include a license to perform any patented applications; therefore it is the sole responsibility of users to determine whether they may be required to engage a license agreement depending upon the particular application in which the product is used.

#### WARRANTY AND LIMITED LIABILITY

The performance characteristics stated were obtained using the assay procedures in the insert. Failure to comply with the instructions may derive inaccurate results. In such event, manufacturer disclaims all warranty expressed, implied or statutory including the implied warranty of merchantability and the fitness of use.

The manufacturer will not be liable for any damage caused by misuse, improper handling and storage; non-compliance with precautions and procedures, and damages caused by events occurring after the product is released.

EvaGreen<sup>®</sup> is a registered trademark of Biotium, Inc. ROX™ is a registered trademark of Applara Corporation, US.

<sup>\*\*</sup>A further 10 cycles can be added to generate the complete amplification plot for low copy number targets which giving late detection.

<sup>\*\*</sup>A post PCR run melt curve can be used to prove the specificity of primers. See the manufactures instructions for your hardware platform.

<sup>\*\*\*</sup>A further 10 cycles can be added to generate the complete amplification plot for low copy number targets which giving late detection.



# ViPrimePLUS *Taq* qPCR Green Master Mix II with ROX (EvaGreen® Dye)

Product code: Packsize:

QLMM17-R

Lot No.: Expiry Date: 150 reactions

**DESCRIPTION** ViPrimePLUS Tag qPCR Green Master Mix II is next generation master mix designed for fast and easy realtime PCR reaction set up. The master mix is prepared in 2X concentrated solution and contains pure Tag DNA Polymerases, EvaGreen® dye, highest quality and buffer components at optimal concentrations. Taq DNA Polymerases in the master mix provide excellent results in reaction efficiency, correlation coefficient and slope. EvaGreen® dye in master mix is environmentally safe and highly stable which can be formulated with relative high dye concentration to maximize fluorescence signal without PCR inhibition.

ViPrimePLUS *Taq* qPCR Green Master Mix II can be used to amplify any DNA template including genomic, cDNA and viral sequences. The formulation of qPCR green master mix can detect low copy number targets very specifically with high efficiency. The qPCR green master mix provides convenient and robust set up for quantitative real-time analysis of DNA samples.

ViPrimePLUS *Taq* qPCR Green Master Mix II has several formulations optimized to be used with most of real-time PCR instruments. The improved sensitivity and consistency of ViPrimePLUS *Taq* qPCR Green Master Mix II in standard cycling conditions gives the industry leading performance in fast cycling conditions.

#### **APPLICATIONS**

All kinds of sample material suited for qPCR amplification can be used.

#### **FEATURES**

- Ready-to-use real-time PCR reaction set up
- Rapid extension rate for early Ct values
- Good buffer system for excellent amplification efficiency
- Contain EvaGreen® dye highest dye stability and safety
- High sensitivity detection
- Minimal PCR inhibition
- Compatible with most of the real-time PCR platforms

## **COMPONENTS**

1.6ml aliquots of master mix

#### STORAGE

Stable at -20°C up to the expiry date stated. Store all components at -20°C upon arrival. Keep in aliquot to reduce freeze-thaw cycles.

#### **QUALITY CONTROL**

As part of the ISO9001:2008 quality assurance systems, each lot of ViPrimePLUS *Taq* qPCR Green Master Mix II has been tested against predetermined specifications to ensure consistent product quality and highest levels of performance and reliability.

#### **LIMITATION OF USE**

For research use only. Not recommended or intended for diagnosis of disease in humans or animals. Do not use internally or externally in humans or animals.

#### **INSTRUMENTS**

To calibrate a real-time PCR reaction, various formulations of master mixes are available for most of the platforms.

# **Master Mixes with Compatible Hardware**

QLMM17

ViPrimePLUS *Taq* qPCR Green Master Mix II (EvaGreen® Dye)

Biometra qTower, BioRad iCycler, BioRad IQ4, BioRad IQ5, Cepheid SmartCycler®, Eppendorf Mastercycler, Fluidigm BioMark™, Illumina Eco, MJ Chromo4, Opticon, PCRMax Eco™, Roche lightcycler® 480, lightcycler® LC96 and lightcycler® Nano Platforms, RotorGene, Roche Capillary Lightcycler 1.0-2.0, Stratagene MX MX4000P®, MX3000P®, MX3005®, Thermo PikoReal™

QLMM17-LR

ViPrimePLUS *Taq* qPCR Green Master Mix II with Low ROX (EvaGreen® Dye)

Applied Biosystems 7500 and 7500 FAST platform, QuantStudio™, ViiA7

QLMM17-R

ViPrimePLUS *Taq* qPCR Green Master Mix II with ROX (EvaGreen® Dye)

Applied Biosystems 7000, 7300, 7700, 7900 and 7900HT FAST platforms, GeneAmp® 5700, StepOne™, StepOne™ PLUS

#### **PROTOCOL**

- 1. Keep the qPCR green master mix protected from light before and after use.
- 2. Aliquot the qPCR green master mix to minimize freeze-thaw cycles and light exposure.
- 3. Reserve plate positions for positive (control DNA) and negative (water or buffer) controls.
- 4. When preparing mixes, always calculate the volume according to the number of reactions that needed plus one extra.
- 5. After the mixture is prepared and aliquoted into tubes, place them into qPCR platform.

#### SUGGESTED MIXTURE

a. When using ViPrimePLUS gene detection kits:

Components	Reaction (1X)
Taq qPCR Green Master Mix II	10µl
Primer/Probe Mix	1µl
Template (25ng)	5µl
Nuclease free water	4µl
Final Volume	20µl

b. When using user's supplied primers and probe:

Components	Reaction (1X)
Taq qPCR Green Master Mix II	10µl
Primers (6pmols Forward & Reverse)	Xμl
Probe (3pmols)	Xμl
Template (25ng)	Xμl
Nuclease free water	Xμl
Final Volume	20µl

#### **CYCLING PROGRAM**

a. For Tagman® gene detection kits

Step	Cycles	Temp	Time
Enzyme activation	1	95°C	2mins
Denaturation	40**	95°C	15secs
Data Collection*		60°C	60secs

<sup>\*</sup>Fluorogenic data should be collected during this step through the FAM channel.

#### b. For EvaGreen® detection kits

Step	Cycles	Temp	Time
Enzyme activation	1	95°C	2mins
Denaturation	40***	95°C	15secs
Data Collection*		60°C	60secs
Melt Curve**			

<sup>\*</sup>Fluorogenic data should be collected during this step through the EvaGreen® channel.

### PREVENTION OF CONTAMINATION

qPCR amplification is a very sensitive DNA amplification reaction; therefore extra care should be taken to eliminate the possibility of contamination with any foreign DNA templates.

- Use separate clean areas for preparation of samples, reaction mixture and for cycling.
- Clean lab bench and equipments periodically with 3% hydrogen peroxide or 70% ethanol.
- Wear fresh gloves. Change gloves whenever suspect that they are contaminated.
- Use sterile tubes and pipette tips with aerosol filters for PCR reaction set up.
- With every PCR reaction set up, perform a contamination control reaction without template DNA.

#### TROUBLESHOOTING

Possibility	Suggestion		
Problem: Negative control / no template control gives positive result			
Carry over contamination	Change nuclease-free water. Use fresh aliquots of reagents. Use filtered tips. Load positive control last.		
Problem: No signal detected			
Incorrect     programming of     instrument	Check program.		
2. Reagents expired	Check the expiry date of reagents before repeat.		
Storage condition not complying with instructions	Check storage condition properly and store at correct storage condition to avoid the degradation of reagents.		
Problem: Early / late signal detected than expected			
Genomic     DNA/RNA     contamination or     multiple products	DNase or RNase treatment of template before qPCR; re- design primers to increase specificity		
Unspecific     products or primer     dimers detected	Re-design primers to increase specificity		
<ol><li>Limiting reagents</li></ol>	Check calculations for master		

3. Limiting reagents or degraded reagents such as master mix

 Poor efficiency during PCR reaction Re-design primers to a different region of the target sequence

fresh stock solutions

5. Unanticipated variants within target sequence

sequence
Keep the GC content to
between 30-50%

mix; repeat experiment using

# LEGAL DISCLAIMER

Purchase of product does not include a license to perform any patented applications; therefore it is the sole responsibility of users to determine whether they may be required to engage a license agreement depending upon the particular application in which the product is used.

#### WARRANTY AND LIMITED LIABILITY

The performance characteristics stated were obtained using the assay procedures in the insert. Failure to comply with the instructions may derive inaccurate results. In such event, manufacturer disclaims all warranty expressed, implied or statutory including the implied warranty of merchantability and the fitness of use.

The manufacturer will not be liable for any damage caused by misuse, improper handling and storage; non-compliance with precautions and procedures, and damages caused by events occurring after the product is released.

EvaGreen<sup>®</sup> is a registered trademark of Biotium, Inc. ROX™ is a registered trademark of Applara Corporation, US.

<sup>\*\*</sup>A further 10 cycles can be added to generate the complete amplification plot for low copy number targets which giving late detection.

<sup>\*\*</sup>A post PCR run melt curve can be used to prove the specificity of primers. See the manufactures instructions for your hardware platform.

<sup>\*\*\*</sup>A further 10 cycles can be added to generate the complete amplification plot for low copy number targets which giving late detection.